

Anziehvorschrift für Zylinderkopf		004.441 passend für / suitable for adaptable à / adaptable a Renault	 Das Original	
Tightening Instructions for Cylinder Head				
Instructions de serrage pour culasse				
Prescripciones de apriete para culatas				
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete		
⑥ ② ③ ⑦ ⑤ ① ④ ⑧				
Anziehen/ Tightening/ Serrage/ Apriete ✱ ► Pos. 1-8: 25 Nm Pos. 1-8: 25 Nm Pos. 1-8: 270° ±20°				
Zeichenerklärung / Explanations / Explication / Explicacion				
✱	neue Zylinderkopfschrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
☐	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
►	Drehwinkel	torque angle	angle de serrage	ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor				
Ø: 73,7 mm; $\frac{1}{2}$: 0,72 mm				
Mot: H4B 0.9 TCe				
Renault Clio IV, Twingo III, Thalia II Dacia Sandero, Captur, Logan II				
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601			*004.441*	