

Anziehvorschrift für Zylinderkopf		071.292 passend für / suitable for adaptable à / adaptable a Renault/Dacia/Nissan	 Das Original	
Tightening Instructions for Cylinder Head				
Instructions de serrage pour culasse				
Prescripciones de apriete para culatas				
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete		
 151.890 M 10x1,5x117				
Anziehen/ Tightening/ Serrage/ Apriete		* 20 Nm ➤ 240°±6°		
Zeichenerklärung / Explanations / Explication / Explicacion				
*	neue Zylinderkopf- schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
□	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor Ø: 80,5 mm; 1.4-1.6 16V ltr. Mot: K4J 700,710-714,730,732,740,750,770 K4M 690,700,701,704,708-711,714,720 724,740,744-748,750,753-754,760-764 Logan, Kubistar, Clio, Kangoo, Laguna, Megane				
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601			*071.292*	