



<b>Anziehvorschrift für Zylinderkopf</b>	<b>135.072</b>	 Das Original
<b>Tightening Instructions for Cylinder Head</b>		
<b>Instructions de serrage pour culasse</b>		
<b>Prescripciones de apriete para culatas</b>		
passend für / suitable for adaptable à / adaptable a		<b>PSA, Fiat, Ford, Volvo</b>

Schraubenkopf / Head shape  
Tête de vis / Cabeza de tornillo

Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete



267.550  
M 12x1,5x126



Anziehen/ Tightening/ Serrage/ Apriete	PSA DW10ATED4: * 20 Nm 60 Nm <input type="checkbox"/> 60 Nm ➤ 110° ➤ 110°	PSA DW12TED4 * 20 Nm 60 Nm <input type="checkbox"/> 20 Nm 60 Nm ➤ 110° ➤ 110°	Fiat, Ford, Volvo: * 30 Nm 60 Nm ➤ 220°
---	--	---	--

Zeichenerklärung / Explanations / Explication / Explicacion

*	neue Zylinderkopfschrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
<input type="checkbox"/>	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro

### Motortyp / Engine type / Type de moteur / Tipo de motor

Ø: 86 mm;  $\pm$ : 1,40 mm; 4 Löcher/holes

Mot: G6DA;G6DB;G6DC;G6DD;G6DE;G6DF;AZWA;  
QXWA;QXWB, DW10ATED4;DW10BTED4;  
DW12TED4;RHR;RHK/DW10UTED4,D4202T/T2

Focus 2004/C-Max →10/03; 307,406,407,607  
807; V40II,V50 →01/04; C4,C5,C8

ElringKlinger AG, Max-Eyth-Str.2  
72581 Dettingen / Erms. Tel. 07123/724 601

**\*135.072\***