


<b>Anziehvorschrift für Zylinderkopf</b>	<b>228.511</b>	
<b>Tightening Instructions for Cylinder Head</b>		
<b>Instructions de serrage pour culasse</b>		
<b>Prescripciones de apriete para culatas</b>		
	passend für / suitable for adaptable à / adaptable a	<b>PSA</b> Das Original

Schraubenkopf / Head shape      Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete  
Tête de vis / Cabeza de tornillo



267.551  
M12x1,5x121

Anziehen/ \*      Pos. 1-10: 20Nm  
Tightening/      Pos. 1-10: 60 Nm  
Serrage/ ►      Pos. 1-10: 220°  
Apriete

Zeichenerklärung / Explanations / Explication / Explicacion

*      neue Zylinderkopfschrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★      Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
□      Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●      Setzzeit	relaxation time	durée de tassement	tiempo de espera
►      Drehwinkel	torque angle	angle de serrage	ángulo de giro

**Motortyp / Engine type / Type de moteur / Tipo de motor**

Ø: 86,5 mm;  $\pm$ : 1,25 mm

Mot:      DW10FC, DW10FCD, DW10FD  
2.0 BlueHDi

308, 3008, 508, 5008

ElringKlinger AG, Max-Eyth-Str.2  
72581 Dettingen / Erms. Tel. 07123/724 601

**\*228.511\***